Packet Tracer - Configure DHCP on a Wireless Router

Objectives

- Connect 3 PCs to a wireless router
- Change the DHCP setting to a specific network range
- Configure the clients to obtain their address via DHCP

Background / Scenario

A home user wants to use a wireless router to connect 3 PCs. All 3 PCs should obtain their address automatically from the wireless router.

Instructions

Part 1: Set up the network topology

- 1. Add three generic PCs.
- 2. Connect each PC to an Ethernet port to the wireless router using straight-through cables.

Part 2: Observe the default DHCP settings

1. After the amber lights have turned green, click **PC0**. Click the **Desktop** tab. Select **IP Configuration**. Select **DHCP** to receive an IP address from **DHCP Enabled Router**.

Record the IP address of the default gateway:

Answer Area 192.168.0.1 Show Answer

- 1. Close the **IP Configuration** window.
- 2. Open a Web Browser.
- 3. Enter the IP address of the default gateway recorded earlier into the URL field. When prompted, enter the username **admin** and password **admin**.
- 4. Scroll through the Basic Setup page to view default settings, including the default IP address of the wireless router.
- Notice that DHCP is enabled, the starting address of the DHCP range and the range of addresses available to clients.

Part 3: Change the default IP address of the wireless router.

- 1. Within the Router IP Settings section, change the IP address to: **192.168.5.1**.
- 2. Scroll to the bottom of the page and click **Save Settings**.
- 3. If it is done correctly, the web page will display an error message. Close the web browser.
- 4. Click **IP** Configuration to renew the assigned IP address. Click **Static**. Click **DHCP** to receive new IP address information from the wireless router.
- 5. Open the web browser, enter the IP address **192.168.5.1** in the URL field. When prompted, enter the username **admin** and password **admin**.

Part 4: Change the default DHCP range of addresses.

- 1. Notice the DHCP Server Start IP Address is updated to the same network as the Router IP.
- 2. Change the Starting IP Address from 192.168.5.100 to 192.168.5.126.
- 3. Change the Maximum Number of Users to **75**.
- 4. Scroll to the bottom of the page and click **Save Settings**. Close the web browser.
- 5. Click **IP** Configuration to renew the assigned IP address. Click **Static**. Click **DHCP** to receive new IP address information from the wireless router.
- 6. Select Command Prompt. Enter ipconfig.

Record the IP address for PC0:

Answer Area **192.168.5.126** Show Answer

Part 5: Enable DHCP on the other PCs.

- 1. Click PC1.
- 2. Select **Desktop** tab.
- 3. Select IP Configuration.
- 4. Click **DHCP**.

Record the IP address for PC1:

Answer Area **192.168.5.127** Show Answer

- 1. Close the configuration window.
- 2. Enable DHCP on **PC2** following the steps for PC1.

Part 6: Verify connectivity

- 1. Click **PC2** and select the **Desktop** tab.
- 2. Select Command Prompt.
- 3. Enter **ipconfig** at the prompt to view the IP configuration.
- 4. At the prompt, enter **ping 192.168.5.1** to ping the wireless router.
- 5. At the prompt, enter **ping 192.168.5.127** to ping PC1.
- 6. The pings to all devices should be successful.